

1264 Full Length 8' Alum Bunk Pair

Instructions

Part #: 1021996

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
-	1	1022128	Bundle - 8' Full Length Alum Bunks
1	2	1022127	Assy 8' Full Length Alum Bunk
-	1	1022130	Hardware Box - 8' Alum Bunk
2	4	1022129	1264 Alum Bunk Bracket
-	1	1022131	Bolt Bag - 8' Alum Bunk
3	4	1001802	Nut Flange 3/8-16 Brass
4	4	1002432	Bolt Hex 3/8-16 x 3.0 SS 304
5	4	1001793	Nut Square 1/2-13 Brass
6	4	1002558	Set Screw 1/2-13 x 1.5 SS

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Determine where you want your bunks positioned, this can be done by either measuring your bunks on your trailer or by measuring your PWC's hull.

Step 2. Attach 8' vinyl bunk to bunk brackets using two 3/8 x 3 hex bolts, and two 3/8 flange nuts per bunk - (as shown).

Step 3. Attach bunks to lift rack by sliding bunk brackets onto the lifts rack, set in desired position, and secure to rack by inserting a 1/2 brass square nut into the nut clip on the bunk brackets and securing in place using a 1/2 x 1-1/2 set screw (do not over tighten).

