

## Universal Wheel Caddy

### Instructions

Part #: 1007018

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	1005798	Prt Plate 10.5 - Universal Lift Caddy
2	2	1005797	Prt Axle - Universal Wheel Caddy
3	2	1007829	Poly Tire 24.0 Dia
4	8	1015730	Bushing 2.015 ID x 3.0 OD x 18Ga
5	8	1002442	Bolt Hex 3/8-16 x 4.5 Full Thread
6	16	1002599	Washer Flat 3/8
7	8	1001805	Nyloc Nut Hex 3/8
8	6	1002569	Pin Cotter 1/4 x 2.5

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

**Step 1.** Attach plates to the side bottom beam of the lift. Secure using four 3/8 x 4-1/2 hex bolts, eight 3/8 washers, four 3/8 nyloc nuts. Position the axle hole toward the bottom.

**Step 2.** Insert shaft through plates. Slide one bushing on the back side and secure with a cotter pin. Then slide another bushing on the front (outside) of the axle and another cotter pin.

**Step 3.** Slide another bushing on the axle to protect the poly wheel from the cotter pin. Then put the poly wheel onto the axle, followed by another bushing and a final cotter pin.

**Note:** If wheel caddy is to be installed as set of two, it should be centered on the lift as shown. If wheel caddy is to be installed as set of four, each should be secured as close to corner of lift as possible.

**Step 4.** Remove poly tires after lift is placed where desired.

