



PRODUCT ASSEMBLY INSTRUCTIONS:



www.wavearmor.net

Parts List:	Tools Needed:
1. #300103 Two-Inch Reducer Bushing	1. Ratchet
2. 3/8" x 1 1/4" Bolt (3)	2. 9/16" Socket
3. Washer (3)	3.
4.	4.
5.	5.
6.	6.

Assembly Instructions:

Installing Item #300103 on the SLX5 or SLX6 Port . Fits 2" pipe with a 2 3/8" outside diameter.

1. At the front of the SLX Port drop the post insert into the anchoring hole. Line up the three holes in the insert with the threaded inserts in the SLX Port. Secure with the 3/8 x 1 1/4 bolts and washers. Repeat on the other side.

