


2" Aluminum Dock Support

Component Identification and Descriptions



Post Cap: Protects dock owner from potentially sharp post top.

Turn Hole: Allows rod to be inserted to turn post (mainly used for augers).

Crossarm Clamp: Connects crossarm to support leg. Allowing easy up and down adjustment with 9/16" socket or wrench.

Stringer Bracket: Connects dock sections to crossarm. Each section comes together end to end and shares this bracket.

Crossarm: Main support for your dock section. Connects to support legs providing crosspiece for dock support.

Support Leg: The legs of the dock support. Length needed is determined by water depth.

Base Pad: This is the foot for your dock support. Cupped and small pads work well for solid lake bottoms. Large pads are available for more stability or softer lake bottoms.

Auger: Allows dock support or tie off post to be secured to lake bottom. Works well in sandy and other semi-solid lake bottoms. Does not work well for rocky or extremely soft lake bottoms.

For any other questions or concerns you have about our 2" aluminum dock supports, please contact us at info@lakefrontfix.com or call 866.942.6349.