


# Round Post Sizing Chart for Solar Dock Lites™

1. Simply fold on 'fold line' to match up the outside diameter of your dock post or the inside diameter of your larger dock post.
2. Place the fold line directly across the center of your dock post. The circle chart will help to determine your dock post size.



**Note:** Remove any post caps before measuring.

Do not mistake the 1 - 7/8" OD for 2" OD. They are very close, so measure carefully and exact.

If you do not see your post size, take an exact measurement of your dock post and contact us. We will do our best to find a mounting option for you.

For more info about Solar Dock Lites, please contact [sales@lakefrontfix.com](mailto:sales@lakefrontfix.com) or [sales@lakelite.com](mailto:sales@lakelite.com).

**\*\*Example\*\***

