

Pontoon Rack

Instructions

Part #: 1006976 - Bolt Bag

1006982 - Pontoon Rack - Bent Rack (Set of 4)

1007020 - Pontoon Rack - V-Rack (Set of 4)

1007006 - Pontoon Rack - Straight Rack (Set of 4)

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	1005685	Pontoon Rack - (Bent Rack Version)
(1)	4	1005816	Pontoon Rack - (V-Rack Version)
(1)	4	1005772	Pontoon Rack - (Straight Rack Version)
-	1	1006976	Bolt Bag
2	8	1002432	Bolt Hex 3/8-16 x 3.0
3	8	1001802	Nut Flange 3/8-16

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Set pontoon racks on the front and rear lift rack in desired positions. Make sure to place the front pontoon racks in line with rear pontoon racks.

Step 2. Insert two 3/8 x 3 hex bolts through bolt holes on the bottom of each of the pontoon racks.

Step 3. Once pontoon racks are in line from front to rear and adjusted to proper distance to fit your pontoon, thread 3/8 flange nuts onto the hex bolts and tighten to secure in place.

